



## The Countryside & Downland Ranges Design and Fitting Guide

**Design - the top and sides:** 10mm will be covered by beading and none of your design in this area will show. You can bleed the background colour to the edges for a finished look but please keep all text clear of these areas.

**Design - the bottom edge:** this area will not be covered by the frame but you do need to consider how you are planning to fit the panel to the frame. If using screws then please leave enough space and advise where you want the holes drilled. See below.

**Artwork:** If your artwork is being printed by us, then it needs to be provided as a press quality PDF with 3mm bleed and printers marks. For best quality reproduction please use images at 200dpi / CMYK. If you are supplying the artwork please sign it off with your designer, changes cannot be made once it has been sent to us and we cannot be held responsible for any errors in the artwork design or quality.

**Design Service:** Don't forget we offer a competitive design and print service. Contact us for more information.

**Fitting the panel to the frame:** the top and sides are covered by a wood beading which is screwed into the frame. This covers the edges but will not keep it in place. For added strength the panel can be affixed to the back of the frame using double-sided tape or mastic. For larger panels such as A2 and above we suggest having 2-3 screw holes made in the panel along the bottom edge. These holes are best done by the print shop. To finish off your design cover the screw heads with a complimentary colour caps from [www.screwcapsuk.com](http://www.screwcapsuk.com).

These notes are just a guide. If you have any questions please speak to us for further guidance.

[www.theacornworkshop.co.uk](http://www.theacornworkshop.co.uk) | 07989 223 634

← **Leave a 10mm border on the top and edges - this area will be covered when the panel is fitted into the frame.**